

QUICK START GUIDE

SI7F





SPECIFICATION

Product Name: Burning Desire Power Source: Special Features: 9 Vibrating modes

Recharging: Run time:

DC charging

Penis ring: 0.9 h: Butt plug: 0.9 h Penis ring: 0.9 h: Butt plug: 1 h

Materials: Medical grade silicone+ABS

Weights: 0.29 lb Size:

Penis ring: 3.3 x 1.7 x 1.4 in: Butt plug: 2.55 x 2.55 x 4.45 in

Waterproof: IPX7

FUNCTION



Power on/off &



Long press "Q, @" for 1.5 seconds to control the product on/off function.

the vibration modes.

The two parts of the massager can be used separately.

When the massager is on, short press the "w " can


remotely switch the vibration mode. Press and hold the "w" for 1.5 seconds to reset the

vibrator.

When the massager is on, long press " U " 1.5 seconds to control the product on/off function.

USB CHARGING

*WARNING: Please DO NOT use adaptor with ">5V" output



- Connect the device to USB port to charge.
- · Do not use the device while charging.
- Please connect with power adapter below 5V.
- Do not submerge under water.
- If the product is not charging while plugged in, please wait 10 minutes and try again.

PRODUCT CLEANING

- Clean: Please wash product with toy cleaner or antibacterial soap and water.
- Drv Pat or wipe dry with clean cloth or towel.
- Store: Keep tov in a cool, dry place.
- Attention: Never clean the toy with abrasive cleaners containing alcohol, gasoline or acetone. Avoid direct sunlight.

SAFFTY

As a close companion of the majority of users, to be able to safely and healthily use this massager is the user and our common responsibility.

We would like to remind you that this product is only suitable for adults over 18 years of age. please keep it away from children. Please do not use excessive force during use, please pay attention to avoid injury. Do not mix this product with others. If you feel unwell during use, stop using the product immediately. Regularly check the product for damage and stop using it immediately if damage is found. This products should be treated as waste electrica and electronic products and recycled to the appropriate waste electrical and electronic products recycling station.

DISCLAIMERS

- Declare that this manual is only for product use tutorials, all interpretation rights belong to the company.
- Please use this product carefuly, any party of any abuse use of this product our company shall not take any responsibility.



Certificates





