



QUICK START GUIDE

SIZE



SPECIFICATION

Materials:	Silicone+ABS	Run time:	60 Minutes
Power Source:	Rechargeable	Recharging:	150 Minutes
Weights:	0.6 lb	Waterproof:	IPX6
Special Features:	7 Vibrating Modes		
	10 Rotating Modes		
	7 Suction Modes		

FUNCTION



Vibrating button

Long press "🌀" for 2s to turn on/off.

Short press "🌀" to change 7 vibrating modes.

Sucking button

Long press "🔌" for 2s to turn on/off.

Short press "🔌" to change 7 sucking modes.

Rotating button


Long press "🌀" for 2s to turn on/off.

Short press "🌀" to change 10 rotating modes.

USB CHARGING

***WARNING: Please do NOT use an adapter with an output greater than 5V.**

***Make sure to fully charge the toy before the first use.**



PRODUCT CLEANING

- Clean: Please wash product with toy cleaner or antibacterial soap and water.
- Dry: Pat or wipe dry with clean cloth or towel.
- Store: Keep toy in a cool, dry place.
- Attention: Never clean the toy with abrasive cleaners containing alcohol, gasoline or acetone. Avoid direct sunlight.

SAFETY

- Do not use it at temperature over 167°F/75 °C.
- Stop using the toy if any discomfort occurs.
- Use with a water-based lubricant.
- Do not use if the product is damaged.
- Keep out of reach of children.



MADE IN CHINA