


# **QUICK START GUIDE**

### SIZE




### **SPECIFICATIONS**

 Material:
 Slicone+ABS
 Charging Time:
 90min

 Noise:
 ≤50dB
 Using Time:
 60min

Functions: 7 Tapping & Flapping & Vibrating Modes Waterproof: IPX6


## **FUNCTION**



- Long press" U" for 2 seconds to enter standby mode.
   Short press "U" to start the first vibration mode. Press again to cycle through the vibration mode. The eighth mode is standby mode (no vibration).
- In standby mode, short press "--" to start the first tickling mode.
   Short press "--" again to switch to the next ticking mode. There are 7 different modes.
- 3. In standby mode, short press "w" to start the first sucking mode. Short press "w" again to switch to the next sucking mode. There are 7 different modes.
- 4. Long press "(1)" for 2 seconds to turn off the device.

### USB CHARGING

\*WARNING: Please DO NOT use adaptor with ">5V" output



- . Connect the device to USB port to charge.
- . Do not use the device while charging.
- . Please connect with power adapter below 5V.
- · Do not submerge under water.
- . If the product is not charging while plugged in, please wait 10 minutes and try again.

#### PRODUCT CLEANING

- 1. Disinfect the product before use: wash with warm water and antibacterial soap, then wipe with
- Do not use massage oil, hand cream, detergent, gasoline, or acetone as lubricant.
- 3. Clean the product as soon as possible after use, as bodily fluids and lubricant residue can breed bacteria if left uncleaned.
- 4. Wash with warm water and soap, suggest to add detergent specialized for sexy toys, disinfectant or 70% alcohol (Long-term use of alcohol is not recommended, as it may damage the product's surface and shorten its lifespan).
- 5.Drying: suggest to wipe with cotton cloth or high quality tissue after washing and then naturally other than exposure under the sunlight.
- 6.Store in a clean, dust-free place, away from other materials.

### SAFETY

As an intimate product, it is our shared responsibility to ensure safe and healthy use. Thus, we remind our customers that:

- 1. This product is for personal use only. Do not share it with others for hygiene reasons.
- In order to meet different demands of different people, this product designed with different vibration frequency. Stop use immediately if you experience discomfort or an allergic reaction.
- 3.Use caution when stimulating the anus. To prevent injury, ensure the product cannot slip inside completely. Using lubricant is recommended for a better experience. Suggest to use together with lubricant to get a better effect. Please stop using if the surface is not smooth or with sharp corners.
- 4. Keep away from children and pets. If any part is accidentally swallowed, seek medical attention immediately.













