





SPECIFICATION

Weights: 0.55 lb Material: Silicone+ABS 7 Vibrating Modes < 5V 1A Mode: Input:

> 7 Tapping Modes Noise: Less than 60db

10 Beads Ring Sliding Modes Charging Time: 120 mins 45 mins

FUNCTION

Using time:



Short press " M " to change between 7 vibrating modes.

Long press " U " for 3s to turn on/off the device Short press " U " to change between 10 thrusting modes.

Short press " O " to change between 7 flapping modes.

USB CHARGING

*WARNING: Please DO NOT use adaptor with ">5V" output

*Please fully charge the product before use. The indicator light will flash
while it is charging and will stop flashing once it is fully charged.

Magnetic
charging

OWERBANK

PRODUCT CLEANING

- Please disinfect the product before use: clean with warm water and antibacterial soap, then wipe with a towel or soft cloth.
- Please do not use massage oil, hand cream, detergent, petroleum, or acetone as a lubricant
- Clean the product as soon as possible after use, as secretions and lubricant residue can easily breed bacteria if left uncleaned for too long.
- Wash with warm water and soap. It is recommended to use a detergent specifically designed for sex toys, a disinfectant, or 70% alcohol. (Note: long-term use of alcohol is not recommended, as it may corrode the product's surface and shorten its lifespan.)
- Drying: It is recommended to wipe with a cotton cloth or high-quality tissue after washing, then allow it to air dry naturally, away from direct sunlight.
- Store in a dust-free environment, without contact with other materials.

SAFFTY

- This product is for personal use only. Please do not share it with others for hygiene and health reasons.
- This product is designed with varying vibration frequencies to meet the needs of different users. If you experience any discomfort or allergic reaction, please stop using it immediately.
- Exercise caution when using this product for anal stimulation to avoid injury. To ensure a better experience, it is recommended to use it with lubricant. Please stop using the product if the surface is rough or has sharp edges.
- Keep this product away from children and pets. If it is ingested by a child or pet, seek medical attention immediately.









