




QUICK START GUIDE

SIZE



SPECIFICATION

Weights: 0.72 lb
Mode: 9 Thrusting Functions
9 Head Vibrations
9 Lip-Biting Vibrations
Using time: 50 mins

Material: Silicone+ABS
Input: < 5V 1A
Noise: Less than 60db
Charging Time: 150 mins

FUNCTION



1. Power On / Vibration

Press and hold the  for 2 seconds to turn on (standby mode). Press once to start head vibration. Press again to cycle through 9 modes + 1 pause.

2. Thrusting

In standby mode, press the  once to activate. Press again to switch through 9 thrusting modes in sequence.

3. Biting / Lip Vibration


In standby mode, press the  once to activate. Press again to switch through 9 biting & lip vibration modes in sequence.

4. Power Off

Press and hold the  for 2 seconds to turn off.

USB CHARGING

***WARNING:** Please DO NOT use adaptor with ">5V" output



- Connect the device to USB port to charge .
- Do not use the device while charging.
- Please connect with power adapter below 5V.
- Do not submerge under water.
- If the product is not charging while plugged in, please wait 10 minutes and try again.

PRODUCT CLEANING

- Clean: Please wash product with toy cleaner or antibacterial soap and water.
- Dry: Pat or wipe dry with clean cloth or towel.
- Store: Keep toy in a cool, dry place.
- Attention: Never clean the toy with abrasive cleaners containing alcohol, gasoline or acetone. Avoid direct sunlight.

SAFETY

- Do not use it at temperature over 167°F/75 °C.
- Stop using the toy if any discomfort occurs.
- Use with a water-based lubricant.
- Do not use if the product is damaged.
- Keep out of reach of children.



Certificates



MADE IN CHINA