

QUICK START GUIDE

SI7F





SPECIFICATION

Product Name: Infinite Intimacy Power Source: USB Magnetic charging Run time:

45 Minutes 120 Minutes

Recharging:


Special Features: 7 Vibrating & Flapping Modes; 5 Biting Modes

Materials: Silicone+ABS

Weights: 0.51 lb Size: 8.4 x 4.3 x 2.7 in

Waterproof: IPX6

FUNCTION



Power Button / Tap Button

Long press the "o" key to turn on the machine, the indicator light is on, vibrate a little, the machine enters the standby mode.

Short press "0" to open the tapping mode, click

to enter the next 1 frequency, a total of 7 frequencies, in order to cycle. Long press to turn

off the machine, each function stops, the indicator light goes out.


Vibrate / Bite Button

In standby mode, short press "@" key to turn on the vibration / bite function, enter the 1st

frequency, click to enter the next 1 frequency, total 5 frequencies, in order to cycle.

USB CHARGING

*WARNING: Please DO NOT use adaptor with ">5V" output



- · Connect the device to USB port to charge.
- Do not use the device while charging.
- . Please connect with power adapter below 5V.
- · Do not submerge under water.
- If the product is not charging while plugged in, please wait 10 minutes and try again.

PRODUCT CLEANING

- Clean: Please wash product with toy cleaner or antibacterial soap and water.
- Dry: Pat or wipe dry with clean cloth or towel.
- . Store: Keep toy in a cool, dry place.
- Attention: Never clean the toy with abrasive cleaners containing alcohol, gasoline or acetone. Avoid direct sunlight.

SAFETY

As a close companion of the majority of users, to be able to safely and healthily use this massager is the user and our common responsibility.

We would like to remind you that this product is only suitable for adults over 18 years of age, please keep it away from children. Please do not use excessive force during use, please pay attention to avoid injury. Do not mix this product with others. If you feel unwell during use, stop using the product immediately, Regularly check the product for damage and stop using it immediately if damage is found. This products should be treated as waste electrica and electronic products and recycled to the appropriate waste electrical and electronic products recycling station.

DISCLAIMERS

- Declare that this manual is only for product use tutorials, all interpretation rights belong to the company.
- Please use this product carefuly, any party of any abuse use of this product our company shall not take any responsibility.







