




## QUICK START GUIDE

### SIZE



### SPECIFICATIONS

Material: Silicone+ABS  
Weights: 1.17lb  
Functions: 10 Thrusting Modes  
10 Vibrating Modes  
Heating Function  
Remote Control

Charging Time: 120min  
Using Time: 60min  
Waterproof: IPX5  
Power Source: Rechargeable

### FUNCTION

Note: The remote control needs the product to be powered on before it works.



#### Product

Long press "⏻" for 3s to turn on/off the device.  
Short press "⏻" to change all modes.

#### Remote control

Short press "⏻" on the remote control to activate standby mode.  
A light prompt will indicate that the dildo can now be controlled via the remote control.


Short press "⏻" to change 10 vibration modes.  
Long press "⏻" for 3s to turn off.

Short press "🌀" to change 10 thrusting modes.  
Long press "🌀" for 3s to turn off.

Short press "🔥" to turn on/off the heating function.

## USB CHARGING

**\*WARNING: Please DO NOT use adaptor with ">5V" output**



Connect the charging cable to the USB charging adapter (you can use a mobile phone charger or your own adapter). Attach the magnetic charging head to the magnetic charging port on the back of the penis/testicle. The red light will flash to indicate that charging is in progress.

## PRODUCT CLEANING

- Please clean the toy thoroughly before and after use.
- Wash it with water after use. Mix it with shower gel or neutral soap detergent. Keep the toy in a ventilated place to dry after washing, before storing. Do not use detergents containing gas or acetone, as they can corrode silicone products.
- Store the product in a cool, ventilated, and dry place. Ensure the product is protected from direct sunlight, high temperatures, heavy pressure, moisture, and any other pollutants.

## SAFETY

- Adult toys are not for use by people under 18.
- For hygiene purposes, we suggest applying a condom to the toy before use.
- We suggest using lube on the thruster to protect your skin.
- Please store it in a dry place, away from direct sunlight and out of the reach of children.
- Cease using it immediately if you experience discomfort.
- Make sure to turn off the power of the dildo and the remote control after use, so as not to affect the use of the battery.
- The product is life waterproof, so it is not recommended to use it directly in water.
- The heating time is about 4-5 minutes, please use it with caution for people who are sensitive to heat.



Certificates



MADE IN CHINA