




QUICK START GUIDE

SIZE



SPECIFICATIONS

Material: Silicone+ABS+ TPE

Weights: 0.76lb


Functions: 10 Vibrating & Flapping Modes;
10 Kissing Modes

Charging Time: 150min

Using Time: 50min

Waterproof: IPX6

FUNCTION



Kissing button

Short press "👄" to change 10 kissing modes.

Long press "👄" for 2s to turn off.

Power button

Long press "🔌" for 2s to turns on/off the toy.


Flapping button

Short press "🌀" to change 10 flapping and vibrating modes.

Long press "🌀" for 2s to turn off.

USB CHARGING

***WARNING: Please DO NOT use adaptor with ">5V" output**



Make sure to fully charge the toy before the first use.

PRODUCT CLEANING

- Clean: Wash the product with warm water and antibacterial soap.
- Wipe: Dry the product with paper towels.
- Save: Keep the product in a cool, dry, and clean place.
- Attention: Never clean the product with organic cleaners that contain alcohol, gasoline, or acetone. Avoid exposure to direct sunlight.

SAFETY

- Do not use the product at temperatures over 167 °F (75 °C).
- Stop using it immediately if you experience any discomfort.
- Water-based lubricant is recommended.
- Do not use the product if you find it rough or damaged.
- Keep out of reach of children.



Certificates



MADE IN CHINA