




QUICK START GUIDE

SIZE



SPECIFICATION

Product Name: Nipple Clamps
Materials: Silicone+ABS
Power Source: Rechargeable
Weights: 0.19 lb
Special Features: 10 Vibrating Modes

Product Size: 3.9 x 2.9 in
Run time: 90 Minutes
Recharging: 90 Minutes
Waterproof: Life Waterproof

FUNCTION



Switch / Frequency Button (nipple clamps)

Long press "⏻" the button for 2s will turn the product on or off.

After entering the standby mode, short press "⏻" on the button will change a vibration level. (10 modes in total)



Pause / Frequency Button (remote control)


After starting vibration, short press "⏸" this button to stop vibration.

Long press "⏸" the button to turn off the product.

After startup, each short press "⏸" on the button will change a vibration level. (10 modes in total)

USB CHARGING

***WARNING: Please DO NOT use adaptor with ">5V" output**



- Connect the device to USB port to charge .
- Do not use the device while charging.
- Please connect with power adapter below 5V.
- Do not submerge under water.
- If the product is not charging while plugged in, please wait 10 minutes and try again.

PRODUCT CLEANING

- Clean: Please wash product with toy cleaner or antibacterial soap and water.
- Dry: Pat or wipe dry with clean cloth or towel.
- Store: Keep toy in a cool, dry place.
- Attention: Never clean the toy with abrasive cleaners containing alcohol, gasoline or acetone. Avoid direct sunlight.

SAFETY

As a close companion of the majority of users, to be able to safely and healthily use this massager is the user and our common responsibility.

We would like to remind you that this product is only suitable for adults over 18 years of age, please keep it away from children. Please do not use excessive force during use, please pay attention to avoid injury. Do not mix this product with others. If you feel unwell during use, stop using the product immediately.

Regularly check the product for damage and stop using it immediately if damage is found. This product should be treated as waste electrical and electronic products and recycled to the appropriate waste electrical and electronic products recycling station.

DISCLAIMERS

- Declare that this manual is only for product use tutorials, all interpretation rights belong to the company.
- Please use this product carefully, any party of any abuse use of this product our company shall not take any responsibility.



MADE IN CHINA