


# QUICK START GUIDE





### SPECIFICATION

Material: Weights: Silicone+ABS 0.39 lb

Special Features: 10 Thrusting Modes 10 Vibrating Modes

Remote Control

Power Source: USB charging Run time: 60 Minutes

Recharging: 150 Minutes Waterproof: IPX6

## FUNCTION



Product

Power button

Long press "6" for 3s to turn on/off the device.

Short press "(b)" to change 10 vibrating and thrusting modes.




Remote control

Power button

Short press " o r to pause/active all modes. Long press " (i) " for 3s to turn off the device.

Short press " m " to change 10 vibrating and thrusting modes.



- Connect the USB cable to the adapter and the other end to the massager.
- . When charging, the ON/OFF button's LED indicator will flash. Once charging is complete, the LED light will stop flashing and remain on. Charging typically takes about 2 hours.
- If the red light on the ON/OFF button flashes during use, it indicates a low battery. Please charge the device.
- Please only use the original charging cable provided.
- You can charge the device by connecting the USB cable to a compatible digital device. We do not provide USB power adapters.

#### PRODUCT CLEANING

- . Clean the product before and after each use. Use warm water (maximum temperature 80°C is recommended) and antibacterial soap. Rinse thoroughly with clean water, and finally wipe it with a dry towel or paper until it is completely dry.
- Do not use cleaners containing alcohol, gasoline, or acetone.
- Please avoid exposing the product to high temperatures or direct sunlight.
- . Please store the product in a clean, dry place, and keep it separate from other massagers.

#### SAFETY

- Please use only water-soluble lubricants when using the product.
- Hand creams or silicone-based lubricants may permanently damage the surface of the product.
- Please clean after use, especially after using lubricants.
- Please read the instructions before use.
- Keep away from children.
- Pregnant women should consult a doctor before using this product. If the silicone layer is damaged, do not use the product.
- . For personal use only. We recommend not sharing the product with others.









