




QUICK START GUIDE

SIZE



SPECIFICATION

Material:	Silicone+ABS	Power Source:	Rechargeable
Special Features:	9 Vibrating Modes	Run time:	45 Minutes
Weights:	0.34 lb	Recharging:	90 Minutes
		Waterproof:	IPX7

FUNCTION

The remote control needs the product to be powered on before it works.



Product

Longpress "⏻" for 1.5 seconds to control the product On/Off function.

In the open state, short press the "⏻" to change the vibration modes.



Remote Control



When the massager is on, short press the "⚡" can remotely switch vibration model.

Press and hold the "⚡" for 1.5 seconds to reset the vibrator.

When the massager is on, long press "⏻" 1.5 seconds to control the product on/off function.

USB CHARGING

***WARNING:** Please DO NOT use adaptor with ">5V" output



- Please make sure your toy is fully charged while the first time
- Please insert the cable into the charge hole.

PRODUCT CLEANING

- Clean: Please clean product with warm water or antibacterial soap.
- Wipe: Dry the product with paper towels.
- Save: Keep the product in a cool, dry and clean place.
- Attention: Never clean this product with organic cleaner that contains alcohol, gasoline or acetone. Avoid direct sunshine.

SAFETY

- Do not use it at temperature over 167 °F/75 °C.
- Stop using it when any discomfort occurs.
- It is recommended to use it with water-based lubricant.
- Do not use it if you find the product unsmooth or damaged.
- Keep out of reach of children.



MADE IN CHINA