




## QUICK START GUIDE

### SIZE




### SPECIFICATION

Power Source:	USB Magnetic charging
Run time:	60 Minutes
Recharging:	120 Minutes
Special Features:	10 Vibrating Modes 3 Thrusting Modes Remote Control

Materials:	Silicone+ABS
Weights:	0.81 lb

Size:	10.4x1.4x1.4in
Waterproof:	IPX5



### FUNCTION

#### ON/OFF

Short press "📶" to change 10 vibrating modes.

Long press "📶" for 2s to pause vibration.

Long press "🔌" for 2s to turn on/off the toy.

Short press "⬆️" to change 3 thrusting modes.

Long press "⬆️" for 2s to pause thrusting.



#### Reset Function

Within 1 minute of turning off the device, short press "⬆️" once to reset the silicone to its lowest position.


#### Auto-Off

In standby mode, the product will automatically turn off after 4 minutes of inactivity.

#### Remote control

When the product is in standby mode, tap once.

The product starts to vibrate and has 10 frequencies. Press and hold for two seconds, the product enters standby mode.




When the product is in standby mode, tap once.

The product starts to expand and contract, with a total of 3 frequencies.

Press and hold for three seconds, the product enters standby mode.

## USB CHARGING

**\*WARNING: Please DO NOT use adaptor with ">5V" output**



- Input voltage: 5V
- Input current: 500mA
- Use a matching charger to avoid damage.
- The indicator will flash while charging and stay on when fully charged.
- The product will automatically enter protection mode during charging and resume after charging is complete.

## PRODUCT CLEANING

- Clean: Please clean product with warm water or antibacterial soap.
- Wipe: Dry the product with paper towels.
- Save: Keep the product in a cool, dry and clean place.
- Attention: Never clean this product with organic cleaner that contains alcohol, gasoline or acetone. Avoid direct sunshine.

## SAFETY

- Read the manual before use and follow the instructions.
- Charge fully before first use.
- Not for use by minors under 18.
- Clean after use with non-corrosive cleaners.
- The product has a built-in lithium battery that cannot be removed. Do not attempt to remove it.
- After use, store in a dry, ventilated place, away from children.
- Dispose of the product properly to protect the environment.



MADE IN CHINA