




QUICK START GUIDE

SIZE



SPECIFICATION

Material:	Silicone+ABS	Power Source:	Rechargeable
Special Features:	3-speed, 9-vibration modes + 6-rotation modes	Run time:	≥50 Minutes
		Recharging:	90 Minutes
		Waterproof:	IPX6
Weights:	0.5 lb		

FUNCTION



- Press and hold: Power ON/OFF
- Short press: Pause





- Short press: Switch between 9 vibration modes
- Press and hold: Turn OFF vibration



- Short press: Activate rotation mode
- Short press again: Cycle through 6 rotation modes
- Press and hold: Stop rotation

USB CHARGING

***WARNING:** Please DO NOT use adaptor with ">5V" output



- Please make sure your toy is fully charged while the first time
- Please insert the cable into the charge hole.

PRODUCT CLEANING

- Clean: Please clean product with warm water or antibacterial soap.
- Wipe: Dry the product with paper towels.
- Save: Keep the product in a cool, dry and clean place.
- Attention: Never clean this product with organic cleaner that contains alcohol, gasoline or acetone. Avoid direct sunshine.

SAFETY

- Do not use it at temperature over 167 °F/75 °C.
- Stop using it when any discomfort occurs.
- It is recommended to use it with water-based lubricant.
- Do not use it if you find the product unsmooth or damaged.
- Keep out of reach of children.



Certificates

UK
CA



MADE IN CHINA