




QUICK START GUIDE

SIZE



SPECIFICATIONS

Material: Silicone+ABS+TPE

Noise: ≤ 60 dB

Product Size: 3.54 x 1.57 x 8.86 in

Functions: 3 Thrusting & Rotating Beads Modes;

7 Vibrating Modes;


7 Tapping Modes

Charging Time: 150min

Using Time: >45min

Waterproof: IPX6

FUNCTION



Long press "⊞" for 2 second to start head Vibrating.

Short press "⊞" to change 7 modes.

Long press "⊞" to power off.

Long press "⊞" for 2 second to start Thrusting, at the same time the bead Rotates 360°.

Short press "⊞" to change 3 modes.

Long press "⊞" to power off.


Long press "⊞" for 2 second to start Tapping.

Short press "⊞" to change 7 modes.

Long press "⊞" to power off.

USB CHARGING

***WARNING: Please DO NOT use adaptor with ">5V" output**



- Connect the device to USB port to charge.
- Do not use the device while charging.
- Please connect with power adapter below 5V.
- Do not submerge under water.
- If the product is not charging while plugged in, please wait 10 minutes and try again.

PRODUCT CLEANING

- Clean: Please clean product with warm water or antibacterial soap.
- Wipe: Dry the product with paper towels.
- Save: Keep the product in a cool, dry and clean place.
- Attention: Never clean this product with organic cleaner that contains alcohol, gasoline or acetone. Avoid direct sunshine.

SAFETY

- Do not use it at temperature over 167 °F/75 °C.
- Stop using it when any discomfort occurs.
- It is recommended to use it with water-based lubricant.
- Do not use it if you find the product unsmooth or damaged.
- Keep out of reach of children.



Certificates



MADE IN CHINA