



QUICK START GUIDE

SIZE








SPECIFICATION

Product Name:	LIPS	Power Source:	USB charging
Material:	Silicone+ABS	Run time:	55 Minutes
Weights:	0.51 lb	Recharging:	120 Minutes
Product Size:	122x71x60mm (4.8x2.8x2.4in)	Waterproof:	IPX6
Special Features:	10 Tongue Licking & Vibrating Modes; 3 Auto Sucking Modes		


FUNCTION



1. Press & Hold the  button to power on the product. It will enter standby mode, and the button will remain illuminated.
2. Press  button once in standby to turn on Tongue Licking & Vibrating & Mouth opening modes at the same time. 10 frequencies to switch between.
3. Press  button once to activate Auto Sucking 3 frequencies to switch between.
4. Hold on  button to keep manual sucking, release to stop sucking.
5. Long press  to turn off the product.

USB CHARGING

***WARNING: Please DO NOT use adaptor with ">5V" output**



- Connect the device to USB port to charge .
- Do not use the device while charging.
- Please connect with power adapter below 5V.
- Do not submerge under water.
- If the product is not charging while plugged in, please wait 10 minutes and try again.

PRODUCT CLEANING

- Clean: Please wash product with toy cleaner or antibacterial soap and water.
- Dry: Pat or wipe dry with clean cloth or towel.
- Store: Keep toy in a cool, dry place.
- Attention: Never clean the toy with abrasive cleaners containing alcohol, gasoline or acetone. Avoid direct sunlight.

FAULT INSTRUCTIONS

- When the machine can not be turned on, check whether there is no power, recharge it before use;
- After charging, it cannot be turned on, check whether the charging indicator is normal, and whether the charging cable is damaged;
- If the indicator light is still flashing after 120 minutes of charging, it might be caused by a charging fault due to poor contact. Please try cleaning the charging cable and port, ensuring a secure connection, and restarting the charging process;
- When the program fails, please shut down and restart

SAFETY

- Do not use it at temperature over 167°F/75 °C.
- Stop using the toy if any discomfort occurs.
- Use with a water-based lubricant.
- Do not use if the product is damaged.
- Keep out of reach of children.



Certificates



MADE IN CHINA