

QUICK START GUIDE

SI7F



8.4in (21.4cm)

SPECIFICATION

 Materials:
 Silicone+ABS
 Product Size:
 8.4 x 1.6in

 Power Source:
 Rechargeable
 Run time:
 60 Minutes

 Weights:
 0.82 lb
 Recharging:
 90 Minutes

 Special Features:
 3 Speeds & 7 Vibrating Modes
 Waterproof:
 Life Waterproof

Water Spary Modes

FUNCTION



Product On/Off Button:

Long press " \circlearrowleft " for 2 seconds, and the indicator light will stay on, indicating that the device is in standby mode.

Short press "O" again to start the vibration function, which has 3 speeds and 7 modes.

Double-press the button to turn the water-spray function on/off.



Remote Control: Shutdown Button:

When the product is working, long press " Δ " for 2 seconds to turn it off.

Vibration Button:

Short press " ∇ " to start the vibration when the power is on. It has 3 speeds and 7 modes.

Long press " ∇ " for 2 seconds to turn the water-spray function on, and Long press " ∇ " for 2 seconds again to stop the spray.



PRODUCT CLEANING

- Cleaning: Wash the dildo with warm water and mild soap, then rinse it with hot water (up to 50°C). Be careful to avoid getting water into the switch and charging port during cleaning. Use your fingers to wash and knead the product, avoiding brushes or harsh, acidic cleaners.
- Wiping: After washing, wipe the product with a lint-free cloth or towel to dry.
- Maintenance: Always turn off the power after use to avoid potential damage to the product or power supply. Store the product in a flannelette or dust bag, and keep it in a cool, dry place.

SAFFTY

- Please do not place the product in any location where heat cannot dissipate.
- This is a personal hygiene item, so do not share it to avoid bacterial infection.
- Although the product has many functions, please avoid overusing it, as excessive use may reduce sensitivity.
- It is recommended to use the product with a condom and professional jubricating fluid for optimal experience
- Please stop using the product immediately if you feel unwell or if it becomes. damaged.
- Do not substitute professional lubricating fluid with massage oils, skin creams. gasoline, acetone, or other chemicals.
- Clean the product immediately after use and store it properly to avoid bacterial infection
- After cleaning and maintenance, store the product in a cool, dry, and private place. If not in use for a long time, recharge it before reuse to prevent battery depletion. For battery-powered products, please remove the batteries before storage.











