


QUICK START GUIDE

SIZE



SPECIFICATIONS

Material: Silicone+ABS Size: 34 ×80 × 247 mm

Mode: 10 Vibration + Digging + Swelling Modes

Charging Time: 90 -120 min Using Time: ≥50 min Waterproof: IPX6

FUNCTION

• Turn ON/OFF:

Press and hold "" button for 2 seconds.

Switch A head frequency settings:

Quickly press " ${\color{orange}0}$ " button to switch A head vibration, digging and swelling frequency cycle;

Double-click the " $\mbox{\ensuremath{\sigma}}"$ to pause A head vibration, digging and swelling frequency cycle;

•Switch B head frequency settings:

Quickly press "~" button to switch B head vibration frequency cycle;

• Double-clik the "~" to pause B head vibration function.

FLASHING light = Charged;


SOLID light = Fully Charged.

Low Battery reminder

the light flashes quickly until it's turned off.

USB CHARGING

*WARNING: Please DO NOT use adaptor with ">5V" output



- Connect the device to USB port to charge.
- Do not use the device while charging.
- Please connect with power adapter below 5V.
- Do not submerge under water.
- If the product is not charging while plugged in, please wait 10 minutes and try again.

PRODUCT CLEANING

- Please clean it thoroughly before and after using.
- Warm water and medicinal alcohol can be used to clean this product, but warm wateris highly recommended.
- · Naturally air dry and avoid direct sunlight.
- Store it in a dust-free place.

SAFETY

- . Don't share it with others for your health.
- Stop using it if you feel uncomfortable.
- Keep it from chidren's reach.

ATTENTION

- Please charge it before using.
- Please use good quality personal lubricant. Something (Massageoil, hand cream or cleaning solution etc.) containing hazardous substances cannot be used as lubricant.













