

SIZE



SPECIFICATION

Materials: Silicone+ABS
Power Source: Rechargeable
Weights: 0.52 lb
Special Features: 8 Tongue Licking
& Vibrating Modes

chargeable Run time: 60 Minutes 2 lb Recharging: 80 Minutes ongue Licking Waterproof: IPX5

Product Size: 3 3 y 2 8in

3 Suction Intensities

FUNCTION



After charging, long press " U" for 1.5 seconds to turn on the product. The device will enter the first gear mode, and the

indicator light will remain on.

Once the product is on, short press " U" to switch between modes. There are 8 tongue-like licking & vibrating modes and 3 suction intensities.

After use, long press " U" for 1.5 seconds to turn off the device.

USB MAGNETIC CHARGING

*WARNING: Please DO NOT use adaptor with ">5V" output



- Use the attached USB cable to connect to the device's charging port.
 Insert the charging end of the cable into the charging position of the device.
- The indicator light will flash during charging and will remain solid when fully charged.
 - Charge the product before first use.
- The product uses DC charging. Please use a charger with matching parameters.
 Using a charger with mismatched parameters may affect battery life or damage the product.
- The product has a built-in current protection feature, which automatically puts it into protection mode while charging, making the product temporarily unusable.
- Once fully charged, the product will automatically return to its normal use state.

PRODUCT CLEANING

- . Apply a cleaning solution to the product surface.
- · Wipe the product clean by hand.
- · Rinse the product repeatedly under running water after cleaning.
- Dry the product by air or with a clean towel.
- After ensuring the product is properly sanitized, store it back in the packaging box.
- After use, ensure the product is clean. Do not use corrosive cleaners.

SAFETY

- This product is not for use by individuals under 18 years of age.
- Do not use at temperatures over 167°F/75°C.
- . Stop using if discomfort occurs.
- It is recommended to use a water-based lubricant.
- . Do not use it if the product is rough or damaged.
- Keep out of reach of children.



