




QUICK START GUIDE


SIZE












SPECIFICATION

Material:	Silicone+ABS	Power Source:	Rechargeable
Special Features:	Biting & Vibration (8 Modes) + Thrusting & Vibration (9 Modes)	Run time:	45 Minutes
		Recharging:	120 Minutes
		Noise:	50-52dB
Weights:	0.77 lb		


FUNCTION



- ◆ Long press the  key to turn on the device while it is turned off, the power indicator light will stay on, and the M20 motor will vibrate once to enter standby
- ◆ Short press the  key to enter the first frequency tapping mode, which will cycle through 9 frequencies in sequence!
- ◆ The display screen will show the corresponding gear position.
- ◆ Short press the  key to enter the first frequency bite vibration mode, which will cycle through 8 frequencies in sequence, and the corresponding gear will be displayed on the screen,
- ◆ Long press the  key to stop the bite function.
- ◆ Short press the  key to enter the head vibration mode, with a total of 8 frequencies in sequence The ring and display screen will have corresponding gear positions displayed
- ◆ Press and hold the  key to stop the head vibration motor.
- ◆ Press and hold the  key to shut down! The motor stops working and enters the shutdown state!
- ◆ Within one minute after shutting down, short press the  key to reset by tapping, and short press the  key to reset by biting.

USB MAGNETIC CHARGING

***WARNING: Please DO NOT use adaptor with ">5V" output**



- Please charge the product when you use it for the first time, the indicator light blinks when charging, and the indicator light is always on when it is full.
- Please use the supplied charging cable for charging. The charging time is ≤ 120 minutes, and the normal operation time after full is >45 minutes.
- Please use a charger that complies with the parameters for charging, charging with a charger that does not comply with the parameters may affect the battery life or cause damage to the product.

Note: Please do not use it while charging.

PRODUCT CLEANING

- Clean: Please clean product with warm water or antibacterial soap.
- Wipe: Dry the product with paper towels.
- Save: Keep the product in a cool, dry and clean place.
- Attention: Never clean this product with organic cleaner that contains alcohol, gasoline or acetone. Avoid direct sunshine.

SAFETY

- Do not use it at temperature over $167^{\circ}\text{F}/75^{\circ}\text{C}$.
- Stop using it when any discomfort occurs.
- It is recommended to use it with water-based lubricant.
- Do not use it if you find the product unsmooth or damaged.
- Keep out of reach of children.



MADE IN CHINA